



Read the set-up instructions carefull. In case of improper use the warranty expires.

## Set-up of the side wall

1. First set up the caravan awning.
2. Take the side wall and open the zipper.
3. Take one of the cross bars.
4. Put the cross bar in the last (closed) part of the side wall.
5. Put the cross bar back in the frame and stretch the cross bar so it remains in the frames. (be careful: When you stretch the cross bar too tight it can damage the caravan.)



6. Close the zipper and the plastic buckle. (see upper mentioned picture)



7. At the front side of the side wall are some loops to attach around the front pole. (see upper mentioned picture)
8. With the multiple tension points The side wall can be fixed at the right height with the multiple elastics and pegs. (elastics and pegs are not included)

Pls take care that when there is a storm you use a tie down kit .

We hope you will enjoy using this Bo-camp product.